Diagnosis and Testing

Pinpoint Test

IGN

TEST STEP				RESULT	ACTION TO TAKE
IGN7 IG	ANITION COIL	RESISTANCE	CHECK		
Disconnect wires from ignition coil.Measure:				Yes	GO to Group 55-04 and perform Quick Test.
	Between	Terminals	Resistance		
A)	Primary	Batt. to Tach.	0.8 to 1.6 ohms	No	REPLACE ignition coil.
B)	Secondary	Batt. to high voltage	6K to 30K ohms		
C)	Insulation	Batt. to case	Above 10M ohms		
• Are r	resistance rea	dings within spe	cifications?		

VEHICLE	A) PRIMARY	B) SECONDARY	C) INSULATION
1.3L EFI			
1.3L FBC			
			A13276-B